2010-2-PAK-NET256

2010-2 PAK increases the network capability to 64 nodes and 256 loops

Overview

The fire panel allows for its capabilities to be extended by use of USB dongles. These USB dongles are called PAK, which stands for Panel Activation Key. The use of the PAK will activate additional high-end feature(s) in the panel. Depending on the required functionality, separate and multiple PAKs can be used to enable these functionalities. Functionalities like number of nodes/loops, supported detector protocol, used TCP/IP communication protocol for remote monitoring, communication towards management software like BACNet or Modbus, etc, can be enabled by usage of the PAKs. The PAK is tied to the serial number of the panel, but does not have to stay connected to the panel. It can be removed once the PAK has been installed, and the feature is enabled in the panel. It is therefore recommend that PAKs stays with the panel at all time, for example in case of performing reset functions or re-installations.

Details

- Increases panel capacity to 64 nodes & 256 loops
- Compatible with panel firmware 3.1. or higher

2010-2-PAK-NET256

2010-2 PAK increases the network capability to 64 nodes and 256 loops

Technical specifications

General

Compatibility	USB type 2.0

Physical

Form factor	Small
Physical dimensions	22 x 70 x 5 mm (W x H x D)
Net weight	75 g
Shipping weight	110 g
Mounting type	In cabinet

Environmental

Operating temperature	-5 to +40°C
Storage temperature	-20 to +50°C
Relative humidity	Max. 95% noncondensing

Regulatory

Certification	EN54-13, EN54-2
Standards	EN54-2 EN54-13
Environmental	CPD WEEE RoHS

Last updated on 5 May 2023 - 9:30